

1. FOOD PREPARATION

Toaster · Grille-pain · Tostapane



TOASTER 1000W BXT01001E

- Stop function to cancel heating immediately.
- 7 browning control settings – toast your bread to suit your taste.
- Removable crumb tray to keep worktops tidy.
- Self-centering, extra-wide slot (38 x 260 mm) accommodates an array of bread types.
- Extra-lift lever raises the toasted slice for safe and easy removal.

- Fonction Stop. Pour arrêter le grill immédiatement.
- 7 Niveaux de grillage pour griller le pain à votre goût.
- Plateau de collecte des miettes pour un comptoir propre et bien rangé.
- Auto-centrage et fente extra large (38x260 mm) pour tous les types de pains.
- Levier d'élévation supplémentaire. Soulever les toasts pour une extraction facile et sans danger.

- Funzione Stop, per fermare immediatamente la cottura.
- 7 Livelli di temperatura, per differenti gusti di tostatura.
- Vassoio raccogli briciole, per una maggiore pulizia e igiene.
- Centrazione automatica e fessura extra large (38x260 mm) per tostare qualsiasi tipo di pane a fette.
- Leva di espulsione del pane. Facilita l'estrazione in modo sicuro.

| | |
|---------------------------------|-----------|
| Power / Puissance / Potenza | 1000W |
| 1 Slot / 1 Fente / 1 Fessura | 38x260 mm |
| Browning / Grillage / Grigliere | 7 |



| MODEL | Product Code | Bar Code | Master Box |
|-----------|--------------|---------------|------------|
| BXT01001E | ES9600053B | 8432406600058 | 4 |